40 mm Beam Pitch General Purpose Area Sensor

NA40 SERIES

FIBER SENSORS Related Information

■ General terms and conditions F-3
■ Glossary of terms / General precautions P.1549~ / P.1552~

LASER SENSORS PHOTOELECTRIC SENSORS

MICRO PHOTOELECTRIC SENSORS

> AREA SENSORS

SAFETY LIGHT
CURTAINS /
SAFETY COMPONENTS
PRESSURE /
FLOW
SENSORS
INDUCTIVE
PROXIMITY
SENSORS

PARTICULAR USE SENSORS

> SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS

STATIC CONTROL DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

ENERGY MANAGEMENT SOLUTIONS

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide Slim Body Picking

NA40







Make sure to use safety light curtains when using a sensing device for personnel protection. Refer to p.455~ for details of safety light curtains.






Slim and smart

ORDER GUIDE

Sensors Mating cable is not supplied with the sensor. Please order it separately.



Note: The model No. with "P" shown on the label affixed to the product is the emitter, "D" shown on the label is the receiver.

ORDER GUIDE

Products that obtained Korea's S-mark certification

We offer products that have obtained Korea's S-mark certification (excluding the sensors with spatter protection hood). When ordering this type, suffix "-K" to the model No. (e.g.) NA40-4 with Korea's S-mark certification is "NA40-4-K".

Mating cable is not supplied with the sensor. Please order it separately. Mating cables

	Appearance	Model No.	Description			
		NA40-CC3	Length: 3 m 9.843 ft Net weight: 600 g approx. (two cables)	0.5 mm² 3-core (for receiver: 4-core) cabtyre cable with connector on one end, two cables per set. Cable outer diameter: ø6.7 mm ø0.264 in		
l		NA40-CC7	Length: 7 m 22.966 ft Net weight: 950 g approx. (two cables)	Connector outer diameter: ø14 mm ø0.551 in max. Cable color: Gray (for emitter) Black (for receiver)		

Accessory

• MS-NA40-1 (Sensor mounting bracket)




Four bracket set Four M5 (length 40 mm 1.575 in) truss head screws, four nuts and four spring washers are attached.

Individual units and associated components can be purchased separately

Designation	Number of	Model No.				
Designation	beam channels	Emitter	Receiver			
Main unit	4	NA40-MUP	NA40-MUD			
Sub-unit	4	NA40-4SUP	NA40-4SUD			
Endusit	2	NA40-2EUP	NA40-2EUD			
End unit	4	NA40-4EUP	NA40-4EUD			
End cap (Note)		NA40-ECP	NA40-ECD			

Note: It is required only for NA40-4 or NA40-4-H.



App	licable beam channels	4 beam channels	6 beam channels	8 beam channels	10 beam channels	12 beam channels	14 beam channels	16 beam channels	20 beam channels	24 beam channels
Protection enclosure	Model No.	MC-NA40-4	MC-NA40-6	MC-NA40-8	MC-NA40-10	MC-NA40-12	MC-NA40-14	MC-NA40-16	MC-NA40-20	MC-NA40-24
With spatter protection hood	Model No.	MC-NA40-4H	MC-NA40-6H	MC-NA40-8H	MC-NA40-10H	MC-NA40-12H	MC-NA40-14H	MC-NA40-16H	MC-NA40-20H	MC-NA40-24H
Front cover	Model No.	FC-NA40-4	FC-NA40-6	FC-NA40-8	FC-NA40-10	FC-NA40-12	FC-NA40-14	FC-NA40-16	FC-NA40-20	FC-NA40-24

Note: The model Nos. given above denote a single unit, not a pair of units.

OPTIONS

App	channels	4 beam channels	6 beam channels	8 beam channels	10 beam channels	12 beam channels	14 beam channels	16 beam channels	20 beam channels	24 beam channels
Slit mask	Model No.	OS-NA40-4	OS-NA40-6	OS-NA40-8	OS-NA40-10	OS-NA40-12	OS-NA40-14	OS-NA40-16	OS-NA40-20	OS-NA40-24

Note: The model Nos. given above denote a single unit, not a pair of units.

Slit mask • OS-NA40-□



Sensing range

- Slit on emitter side: 1.3 m 4.265 ft
- Slit on receiver side: 3 m 9.843 ft

• Slit on both sides: 0.8 m 2.625 ft

FIBER SENSORS

LASER SENSORS

PHOTO-ELECTRIC SENSORS

SAFETY LIGHT CURTAINS / SAFETY COMPONENTS PRESSURE / FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS

STATIC CONTROL DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES ENERGY MANAGEMENT SOLUTIONS

FA COMPONENTS

MACHINE VISION SYSTEMS UV CURING SYSTEMS

Slim Body Picking

NA40

FIBER SENSORS

LASER SENSORS PHOTO-ELECTRIC SENSORS

AREA SENSORS SAFETY LIGHT CURTAINS / SAFETY COMPONENTS PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS

STATIC CONTROL DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

COMPONENTS FA

MACHINE VISION SYSTEMS UV CURING SYSTEMS

Selection Guide Slim Body Picking

NA40


OPTIONS

Designation	Model No.	Description
Large indicator for area sensor	SF-IND	With the large indicators put on the sensors, the operation is easily observable from various directions. Orange.

Note: Two **SF-IND**s are required if they are to be mounted on, both, the emitter and the receiver.

Large indicator for area sensor

• SF-IND




The large indicator can be easily mounted on the sensor head at the top. It also can be mounted on an area sensor already being

SPECIFICATIONS

	Number of beam channels	4	6	8	10	12	14	16	20	24
	Model No.	NA40-4	NA40-6	NA40-8	NA40-10	NA40-12	NA40-14	NA40-16	NA40-20	NA40-24
Iter	m With spatter protection hood	NA40-4-H	NA40-6-H	NA40-8-H	NA40-10-H	NA40-12-H	NA40-14-H	NA40-16-H	NA40-20-H	NA40-24-H
Ser	nsing height	120 mm 4.724 in	200 mm 7.874 in	280 mm 11.024 in	360 mm 14.173 in	440 mm 17.323 in	520 mm 20.472 in	600 mm 23.622 in	760 mm 29.921 in	920 mm 36.220 ii
Ser	nsing range					5 m 16.404 ft				
Bea	am pitch				4	40 mm 1.575 ii	า			
Sen	nsing object				ø60 mm ø2.3	62 in or more	opaque object			
Sup	oply voltage			12	to 24 V DC ±1	10 % Ripple F	P-P 10 % or le	ss		
Cur	rent consumption		ter: 30 mA or I eiver: 60 mA o		Emitter: 3	55 mA or less,	Receiver: 90 r	mA or less	Emitter: 35 r Receiver: 11	nA or less 5 mA or less
Ser	sing output			 Maximun Applied v 					/)	
	Output operation		ON when all I	peam channel	s are received	/ OFF when o	ne or more be	am channels a	are interrupted	
	Short-circuit protection					Incorporated				
Self	f-diagnosis output	NPN open-collector transistor • Maximum sink current: 50 mA • Applied voltage: 30 V DC or less (between self-diagnosis output and 0 V) • Residual voltage: 1.6 V or less (at 50 mA sink current)								
	Output operation	OFF when unstable light received condition continues for 5 sec. or more, or the output transistor fails								
	Short-circuit protection	Incorporated								
Res	sponse time					12 ms or less				
Indicator		Incorporated with the three color indicators on the receiver • Sensing output operation indicator: Red LED (lights up when one or more beam channels are interrupted) • Stable incident beam indicator: Green LED (lights up when all beam channels are received stably) • Unstable incident beam indicator: Yellow LED (lights up when one or more beam channels are received unstably) * When the output transistor fails, the three color indicators blink simultaneously.								
Inte	rference prevention function	Incorporated (Two units of sensors can be mounted close together.)								
	Protection	IP65 (IEC)								
nce	Ambient temperature	-10 to +50 °C +14 to +122 °F (No dew condensation or icing allowed), Storage: -10 to +60 °C +14 to +140 °F								
Environmental resistance	Ambient humidity	35 to 85 % RH, Storage: 35 to 85 % RH								
talre	Ambient illuminance			Incan	descent light:	3,500 {x or les	s at the light-re	eceiving face		
ment	Voltage withstandability	1,000 V AC for one min. between all supply terminals connected together and enclosure								
/iron	Insulation resistance	20 MΩ, or more, with 500 V DC megger between all supply terminals connected together and enclosure								
Ë	Vibration resistance	10 to 55 Hz frequency, 1.5 mm 0.059 in double amplitude in X, Y and Z directions for two hours each								
Shock resistance			100 m/s² acceleration (10 G approx.) in X, Y and Z directions three times each							
Emi	itting element		Infrared LED (synchronized scanning system)							
Material			Protection enclosure: Aluminum, Unit case: ABS, Front cover: Acrylic, Lens: Acrylic							
Cat	ble	0.5 mm ² 4-core (emitter: 3-core) cabtyre cable, 0.5 m 1.640 ft long, with a round connector at the end * Use together with the optional mating cable								
Cat	ole extension	Extension up to total 100 m 328.084 ft is possible, for both emitter and receiver, with 0.5 mm ² , or more, cable. (However, the interference prevention wire can extend up to 20 m 65.617 ft between two emitters.)								
Net v	weight (Total of emitter and receiver)	400 g approx.	500 g approx.	630 g approx.	770 g approx.	890 g approx.	1,020 g approx.	1,150 g approx.	1,400 g approx.	1,660 g approx
	With spatter protection hood	500 g approx.	630 g approx.	800 g approx.	990 g approx.	1,150 g approx.	1,330 g approx.	1,500 g approx.	1,840 g approx.	2,190 g approx
	ccessories MS-NA40-1 (Sensor mounting bracket): 1 set for emitter and receiver, Adjusting screwdriver: 1 pc.									

I/O CIRCUIT DIAGRAMS

I/O circuit diagrams



Symbols ... D: Reverse supply polarity protection diode


Notes: 1) If the interference prevention wires (orange/violet) are not used, please insulate them.

 Never connect the emitter's interference prevention wire (orange/violet) to the receiver's self-diagnosis output (orange). This can cause damage.

Connector pin position


Emitter

Interference prevention wire (Oranger/Violet) 20 01 +V (Brown) 130 04 NC



Symbols ... D: Reverse supply polarity protection diode Z_{D1}, Z_{D2}: Surge absorption zener diode Tr₁, Tr₂: NPN output transistor

Receiver



Refer to p.1552~ for general precautions.

PRECAUTIONS FOR PROPER USE

• Never use this product as a sensing device for personnel protection.



- For sensing devices to be used as safety devices for press machines or forpersonnel protection, use products which meet standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.
- If this product is used as a sensing device for personnel protection, death or serious body injury could result.
- For a product which meets safety standards, use the safety light curtains. (p.455~)

Setting of interference prevention function

- Make sure that the power supply is off while operating the frequency selection switch. If the switch is operated while the power is on, the sensor may go into the operation stopped state. However, to restart the sensor, turn the power off and on again.
- The frequency selection switch should not be set to the positions other than those specified below.
- When the sensor A breaks down due to any reason, the sensor B goes into the operation stopped state. In order to check the operation of the sensor B, set the frequency selection switch to '1'. Note that when only the sensor B breaks down, the sensor A keeps operation correctly.
- When the interference prevention function is not used (when one set of sensor is used) make sure that the frequency selection switch in both the emitter and receiver is set to '1'. If the switch is set to other than that, the sensor may not operate properly.

When using one set of sensor

Frequency selection switches				
Emitter	Receiver			
2 3 P	2 3			

Set the switches of both the emitter and the receiver at '1'. The sensor does not function normally at other settings.

When using two sets of sensor

 Up to two sets of sensors can be mounted close together by using the interference prevention function. Set the interference prevention function in the following procedure.

①Set the frequency selection switch. Firstly, push up the front cover while pressing the cover stopper towards the arrow shown in the right figure.

②Turn the frequency selection switch with the accessory adjusting screwdriver to select the frequency.

	Frequency selection switches				
	Emitter	Receiver			
Sensor A	2 A	72 3 h			
Sensor B		7 7			

Sensor B
Sensor A
Sensor A
Cover stopper
Front cover

Sensing Area B

Set the switches of both the emitter and the receiver of Sensor A at '1', and both switches of Sensor B at '2'. The sensors do not function normally at other settings.

③Connect the interference prevention wire (INTER LOCK) of Sensor A and B.



- Connect both the 0 V wires in common.
- +V wires need not be connected in common.

Note: Total of wire length between Sensor A and B is 20 m 65.617 ft max. (Total of wire length of interference prevention wire and 0 V is 20 m 65.617 ft max.)

FIBER SENSORS

LASER SENSORS

PHOTO-ELECTRIC SENSORS MICRO PHOTO-ELECTRIC

AREA SENSORS

PRESSURE / FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

> SENSOR OPTIONS

WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS STATIC

CONTROL

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES ENERGY MANAGEMENT

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide Slim Body Picking

NA40

FIBER SENSORS

LASER SENSORS PHOTO-ELECTRIC SENSORS

COMPONENTS

SENSORS PARTICULAR USE SENSORS

PRESSURE /

SENSOR OPTIONS SIMPLE WIRE-SAVING UNITS

MEASURE-MENT SENSORS

STATIC CONTROL DEVICES LASER MARKERS

PLC HUMAN MACHINE INTERFACES

FA COMPONENTS MACHINE VISION SYSTEMS

CURING SYSTEMS


Slim Body Picking

NA40

DIMENSIONS (Unit: mm in)


The CAD data can be downloaded from our website.

NA40-□



Model No.	Α	В	С
NA40-4	120	163	180
	4.724	6.417	7.087
NA40-6	200	233	250
	7.874	9.173	9.843
NA40-8	280	313	330
	11.024	12.323	12.992
NA40-10	360	393	410
	14.173	15.472	16.142
NA40-12	440	473	490
	17.323	18.622	19.291
NA40-14	520	553	570
	20.472	21.772	22.441
NA40-16	600	633	650
	23.622	24.921	25.591
NA40-20	760	793	810
	29.921	31.220	31.890
NA40-24	920	953	970
	36.220	37.520	38.189

NA40-□-H



Model No.	Α	В	С
NA40-4-H	120	163	180
	4.724	6.417	7.087
NA40-6-H	200	233	250
	7.874	9.173	9.843
NA40-8-H	280	313	330
	11.024	12.323	12.992
NA40-10-H	360	393	410
	14.173	15.472	16.142
NA40-12-H	440	473	490
	17.323	18.622	19.291
NA40-14-H	520	553	570
	20.472	21.772	22.441
NA40-16-H	600	633	650
	23.622	24.921	25.591
NA40-20-H	760	793	810
	29.921	31.220	31.890
NA40-24-H	920	953	970
	36.220	37.520	38.189


DIMENSIONS (Unit: mm in)

The CAD data can be downloaded from our website.

MS-NA40-1

Sensor mounting bracket (Accessory)

23.5 0.925 18 ±02 0.709 ±0.008 18 ±02 0.709 ±0.008 10.217 0.768 0.630 0.448 0.630 0.448 0.630 0.448 0.630 0.448 0.630 0.448



Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated)


Four bracket set

4 pcs. each of M5 (length 40 mm 1.575 in) truss head screws, nuts and spring washers are attached.

Assembly dimensions

Mounting drawing with **NA40-**□.

The assembly for the spatter protection hood type (NA40-u-H) is similar.



Model No.	Α	D	E
NA40-4(-H)	120	200	210
	4.724	7.874	8.268
NA40-6(-H)	200	270	280
	7.874	10.630	11.024
NA40-8(-H)	280	350	360
	11.024	13.780	14.173
NA40-10(-H)	360	430	440
	14.173	16.929	17.323
NA40-12(-H)	440	510	520
	17.323	20.079	20.472
NA40-14(-H)	520	590	600
	20.472	23.228	23.622
NA40-16(-H)	600	670	680
	23.622	26.378	26.772
NA40-20(-H)	760	830	840
	29.921	32.677	33.071
NA40-24(-H)	920	990	1,000
	36.220	38.976	39.370


SF-IND


Large indicator for area sensor (Optional)

Assembly dimensions

Mounting drawing with **NA40**-□ on which a sensor mounting bracket is attached.

The assembly for the spatter protection hood type (NA40- \square -H) is similar.





Model No.	Ш	F
NA40-4(-H)	210 8.268	223 8.780
NA40-6(-H)	280 11.024	293 11.535
NA40-8(-H)	360 14.173	373 14.685
NA40-10(-H)	440 17.323	453 17.835
NA40-12(-H)	520 20.472	533 20.984
NA40-14(-H)	600 23.622	613 24.134
NA40-16(-H)	680 26.772	693 27.283
NA40-20(-H)	840 33.071	853 33.583
NA40-24(-H)	1,000 39.370	1,013 39.882

BER NSORS

LASER SENSORS

PHOTO-ELECTRIC SENSORS MICRO PHOTO-ELECTRIC

AREA SENSORS

SAFETY LIGHT CURTAINS / SAFETY COMPONENTS PRESSURE / FLOW SENSORS

SENSORS INDUCTIVE

PARTICULAR USE SENSORS

SENSOR OPTIONS SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS MEASURE-MENT SENSORS

STATIC CONTROL DEVICES LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

ENERGY MANAGEMENT SOLUTIONS FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide Slim Body

NA40